

Assembly Instructions

Thank you for purchasing a **Birlea** product.


For a chance to win a *Love 2 Shop* voucher simply post a picture of your new product on your preferred social channels tagging Birlea Furniture and using the hashtag **#ShareYourStyle** and **#Birlea**. One winner will be selected at random each month.

To view our full terms and conditions please visit our website. www.birlea.com

Are you happy with your purchase?

- *Yes:* That's great, we would love to hear more from you. Please leave us a review on our social media channels or Trustpilot. Your feedback will be greatly appreciated.
- *No:* If for any reason there is something missing, indifferent or incorrect with your order, please contact the retailer you purchased the item from. We will work with the retailer to resolve your issue as quickly as possible.







ASSEMBLY INSTRUCTION

COMPUTER GAMING CHAIR

IMPORTANT! READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

Assembly to be carried out by a competent adult only.

Assemble the furniture on a soft level surface to avoid damaging the product or your floor.

During assembly children should be kept away from the product due to the possible risk of injury.

Do not use the chair unless all screws are fully tightened, check this every 3 months and re-tighten if necessary.

Only trained personnel may replace or repair seat height adjustment components with energy accumulators.

For safety reasons the castors are designed to lock automatically, when the chair is not in use. The lock is released automatically when the seat is loaded.

Ensure that fingers and legs are clear of all adjustments when adjusting this product.

Do not use this chair as a stepladder.

Use this product only for seating one person at a time.

Please be warmed that there is a risk of falling when the chair is in a fully tilted position. Do not let anyone press on the backrest while the seat is in a leaning position.

This desk chair is tested for domestic use. Tested for 110 kg.


Care and Maintenance of your Furniture

Wipe clean with a damp cloth. Use only clean water.

Dust and dirt can be vacuum cleaned or wiped with a clean soft cloth. Do not use detergents, solvents or other chemicals on surface as this may cause discoloration.

CAUTION: FREQUENT EXPOSURE TO DIRECT SUNLIGHT OR SIMILAR SOURCES MAY CAUSE THE SURFACE TO DISCOLOUR OR FADE.






Parts List										
PART	DESCRIPTION	QTY	BOX	PART	DESCRIPTION	QTY	BOX			
1	Backrest	1	1	7	Left Armrest	1	1			
2	Headrest	1	1	8	Mechanism	1	1			
3	Right Plastic Cover	1	1	9	Telescoping Cover	1	1			
4	Left Plastic Cover	1	1	10	Gas Lift	1	1			
5	Seat Cushion	1	1	11	Star Base	1	1			
6	Right Armrest	1	1	12	Castor	5	1			

HARDWARE (IN BOX 1)


Α		M8x20mm	16
В	\bigcirc	Ø17xØ8.5x1mm	4
С		M5x8mm	4

D	M5x10mm	2
E		1





















09






Do NOT place this chair near heat sources, windows or under the sunshine.

Do NOT use the chair if any part is broken, torn or missing and use only spare parts approved by the manufacturer.



Functional introduction:



WARNING!

Please do not lie down before you lock the base, there is a risk of falling when the chair is in a fully tilted position.

Do not put your weight on the backrest. Weight must be on the seat itself. Do not let anyone press down on the backrest while the seat is in a leaning position.



Additional Information:

- For complete product information, images and dimension diagrams please visit the website <u>www.birlea.com</u>
- If you have any issues with your item please contact the retailer directly you purchased it from who will be able to resolve any issues with Birlea.
- Why don't you send us photos of your assembled furniture to <u>info@birlea.com</u> to be shared in our #birleahome feature on Instagram.

