




## STEP 5

Attach the left hand Arm onto the Seat Back and Seat Frame, not completely tightening the bolts.



## STEP 6

Securely tightened all bolts and place the Screw Hole Covers in place. Adjust feet for balance.




# KY474 ACCENT CHAIR

Thank you for your purchase. The following care instructions will allow you to make the most of your chair; helping to prolong the look and life of it by preventing wear and damage.

## STEP 7

Once you are happy with the assembly of your chair, it is ready for use.



### IMPORTANT INFORMATION

**PLEASE ENSURE YOU READ THIS LEAFLET BEFORE USING YOUR CHAIR. DO NOT DISCARD OF ANY PACKAGING UNTIL YOU HAVE CHECKED THE PRODUCT THOROUGHLY.**

### CARING FOR YOUR CHAIR

- Pre-brush fabric with a soft brush and then gently vacuum.
- Plump any accent/removable cushions regularly to prevent them becoming mis-shaped or flat.
- Use a microfibre cloth to remove dust from wooden surfaces.
- In the event of a spill or stain, use specialist upholstery cleaner or cleaning services.

### SUNLIGHT AND HEAT DAMAGE

- Avoid contact with direct sunlight. If needed, move items or change their position to avoid the same area being exposed to repeated sunlight/heat.
- Do not place your chair close to fire places and/or radiators.
- Hot objects such as mugs/plates can permanently mark the fabric and wood, avoid placing these on the chair.

FABRIC CONTENT  
MAIN FABRIC 100% POLYESTER  
OTHER FABRIC (VISIBLE)  
NON-WOVEN FABRIC 100% POLYESTER

## SAFETY WARNINGS

- Do not allow children or pets to climb or jump on the chair or through the arms.
- Avoid contact with sharp objects such as buckles, toys and jewellery as these can easily snag, tear and/or pull the fabric.
- Avoid the risk of entrapment by using the chair as intended; sitting facing forward on the seat.
- Keep small parts away and out of reach of children and pets.

## PARTS LIST

IMAGE	NAME	PART	QTY	IMAGE	NAME	PART	QTY
	Back	A	1		M8 x 65MM Bolt	I	16
	Seat	B	1		M8 x 45MM Bolt	J	2
	Seat Frame	C	1		M8 x 22MM Washer	K	12
	Arm	D	1		M8 x 30MM Washer	L	4
	Arm	E	1		Spring Washer	M	16
	Front Legs	F	1		Screw Hole Covers	N	2
	Back Left Leg	G	1		Allen Key	O	1
	Back Right Leg	H	1				

## ASSEMBLY INSTRUCTIONS


Unpack your sofa bed and check that all the parts on the Parts List are present - these may be in a zip compartment within the base. If any are missing, please contact the retailer from whom you purchased the product.

We would advise having 2 people to assemble this product.

Assemble your chair on a flat, soft surface to prevent any damage.


### STEP 1

Attach the Legs to the Seat Frame, but do not tighten bolts completely yet.




### STEP 2

Attach the Seat Frame with the Legs to the Seat Back, again, do not tighten bolts completely yet.



### STEP 3

Attach the right hand Arm onto the Seat Back and Seat Frame, not completely tightening the bolts.



### STEP 4

Slot the Seat Cushion onto the Seat Frame.

