

Assembly Instructions

Thank you for purchasing a Birlea product

For a chance to win a Love2Shop voucher simply post a picture of your new product on your preferred social channels tagging Birlea Furniture. One winner will be selected at random each month.

*Terms & conditions may apply.

Are you happy with your purchase?

Yes: That's great, we would love to hear more from you. Please leave us a review on our Trustpilot link on the QR code here. Your feedback will be greatly appreciated.



No: If for any reason there is something missing, indifferent or incorrect with your order, please contact the retailer that you purchased your item from.

Please note that this items build time is around: 30mins



ASSEMBLY INSTRUCTIONS AXEL CONSOLE TABLE

IMPORTANT: READ THESE INSTRUCTIONS CAREFULLY BEFORE ASSEMBLING OR USING YOUR AXEL CONSOLE TABLE.

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.

ASSEMBLY:

Assembly should be carried out with this item laying flat, not standing upright.

Assemble on a soft, clean surface to prevent damages.

To erase the numbers printed on the pieces, use the rubber inside the accessories pack.

HEALTH & SAFETY:

DO NOT use this product if any parts are missing, damaged or worn.

DO NOT use this product unless all fixings are secured.

Always use on a level, even surface.

CARE & MAINTENANCE:

Periodically check all screws & fixings to ensure they are secure.


DO NOT push this product as this will cause damage.

Always lift this product with two people to repositions.

Keep any sharp objects away from this product.







Parts List				Hardware List		
Part	Description	Box	QTY	Part	Description	QTY
1	Side Panel(Left)	1	1	Α	Cam Bolt	6
2	Side Panel(Right)	1	1	В	Cam Lock	6
3	Top Panel	1	1	С	Wooden Dowel	16
4	Bottom Panel	1	1	Х	Screw 00	8
5	Side Panel(Middle)	1	1	Е	Handle Set	2
6	Back Panel	1	1	F	Screw	16
7	Door Panel	1	2	Т	Screw (c) (minimum)	10
8	Connect Panel(Left&Right)	1	2	Н	Foot Pad	4
9	Connect Panel(Front&Back)	1	2	I	Plastic Wedge Set	6
10	Wooden Leg	1	4	J	Screw	6
11	Coner Connect Panel	1	4	K	Sticker	6
				L	Allen Key	1
				М	Washer	2
				N	Safe Strap	2
				Q	Screw (*)	2



^{**} You will need a small mallet and a screwdriver for assembly.


^{**} Some screws and wooden dowel may remain.

^{**} Note: To secure the item to the wall.

STEP 1: Attach the top panel (3) with side panel (1),(2),(5) by hardware (A, B,C,K).


DO NOT use any power tools as this may damage the frame and will invalidate any claim.

AX6
BX6
CX6
KX6



STEP 2: Insert the back panel(6) with side panel (1),(2).


DO NOT use any power tools as this may damage the frame and will invalidate any claim.



STEP 3: Attach the bottom panel(4) with side panels(1),(2),(5) by hardware (C,J,L);

DO NOT use any power tools as this may damage the frame and will invalidate any claim.


CX6
JX6
LX1



STEP 4: Attach the handle(E) with door panel (7).


DO NOT use any power tools as this may damage the frame and will invalidate any claim.

EX2




STEP 5: Connect panel (8),(9) together with (11) by hardware F.

DO NOT use any power tools as this may damage the frame and will invalidate any claim.



STEP 6: Attach the frame with bottom panel (4) by hardware (C,T).


DO NOT use any power tools as this may damage the frame and will invalidate any claim.



STEP 7: Attach the leg(10) by hardware (X); Then, attach the foot pad (H);
Attach the hardware (I) on the back.


DO NOT use any power tools as this may damage the frame and will invalidate any claim.





STEP 8: Insert two doors (7) by sliding each panel into the routered grooves at the back of the unit.


DO NOT use any power tools as this may damage the frame and will invalidate any claim.



STEP 9: Secrue the safty strap(N) by hardware (M,Q).

DO NOT use any power tools as this may damage the frame and will invalidate any claim.





PLEASE NOTE that wall fixings are not supplied as different wall materials require different fixing devices. You must use fixings devices suitable for the type of wall you intend to mount product to. Ensure the head of any screw used has a diameter greater than the mounting hole and the fixing is safe and secure before use.



In order to prevent overturning this product must be used with the wall attachment device provided. Serious or fatal crushing injuries can occur from furniture tipping over. To help prevent topple over:-

- Use the wall attachment devices provided
- Never allow children to climb or hang on drawers or doors
- Do not overload the drawer beyond maximum recommended loading
- Place heaviest items in the lower drawers or shelves
- Unless specifically designed to accommodate, do not set TV's or other heavy objects on top of this product
- Never open more than one drawer at a time
- Do not hang things from the doors

An attachment device is provided with your product, however you will need to source suitable fixings for your wall type. If in doubt consult a qualified trades person.

Always ensure that the wall to be drilled into is free from hidden electrical wire, water and gas pipe.

Birlea Furniture advise that the wall straps provided should be used to further enhance the safety of this product.

Additional Information:

- · For complete product information, images and dimension diagrams please visit the website www.birlea.com
- · If you have any issues with your item please contact the retailer directly you purchased it from who will be able to resolve any issues with Birlea.
- · Why don't you send us photos of your assembled furniture to <u>info@birlea.com</u> to be shared in our #birleahome feature on instagram.

