


GREY GLOSS SEVILLE 3+2 DRAWER CHEST ASSEMBLY INSTRUCTIONS



FOR DOMESTIC USE ONLY
IMPORTANT

PLEASE READ BEFORE YOU CONTINUE FURTHER

THE PRODUCT YOU HAVE PURCHASED WILL GIVE YOU MANY YEARS OF SERVICE IF YOU FOLLOW THE GUIDELINES FOR ITS SAFE ASSEMBLY AND PERIODIC MAINTENANCE AND CLEANING.

ASSEMBLE ON A SOFT CLEAN SURFACE.

DO NOT USE ANY TOOLS OTHER THAN THOSE SHOWN.


ANY SPANNERS OR ALLEN KEYS REQUIRED ARE INCLUDED WITH THE FITTING KIT.

DO NOT FOR ANY REASON USE A POWER TOOL TO ASSEMBLE THIS PRODUCT. ITS USE WILL INVALIDATE ANY CLAIM YOU MAY HAVE AND COULD MAKE THIS PRODUCT UNSAFE.

DEPENDING ON THE AMOUNT OF USE THIS PRODUCT RECEIVES, IT MAY BE NECESSARY TO TIGHTEN UP THE FIXINGS FROM TIME TO TIME. THIS IS COMPLETELY NORMAL FOR ANY FLAT PACK FURNITURE. DO NOT OVERTIGHTEN FIXINGS.

FOR CLEANING, YOU MAY USE A DAMP CLOTH (NOT WET). DO NOT USE POLISH, DETERGENT OR CHEMICAL CLEANERS.






THIS SURFACE OF THIS ITEM IS NOT HEAT RESISTANT. ALWAYS USE A PLACE MAT UNDER HOT OR COLD ITEMS TO PREVENT MARKING.





PART LIST

| Part Number | Part Code | Part Description | Quantity | Carton |
|-------------|---------------------|--------------------------|----------|--------|
| 1 | S100-102-086-ZF1-01 | Left Side Panel | 1 | 1/2 |
| 2 | S100-102-086-ZF1-02 | Right Side Panel | 1 | 1/2 |
| 3 | S100-102-086-ZF1-03 | Centre Panel | 1 | 2/2 |
| 4 | S100-102-086-ZF1-04 | Drawer Front Large | 3 | 1/2 |
| 5 | S100-102-086-ZF1-05 | Left Drawer Front Small | 1 | 2/2 |
| 6 | S100-102-086-ZF1-06 | Left Drawer Side | 5 | 1/2 |
| 7 | S100-102-086-ZF1-07 | Right Drawer Side | 5 | 1/2 |
| 8 | S100-102-086-ZF1-08 | Top Panel | 1 | 1/2 |
| 9 | S100-102-086-ZF1-09 | Crossbar | 2 | 1/2 |
| 10 | S100-102-086-ZF1-10 | Centre Support | 2 | 1/2 |
| 11 | S100-102-086-ZF1-11 | Support Top | 2 | 1/2 |
| 12 | S100-102-086-ZF1-12 | Support Panel | 2 | 1/2 |
| 13 | S100-102-086-ZF1-13 | Drawer Back Large | 3 | 2/2 |
| 14 | S100-102-086-ZF1-14 | Drawer Back Small | 2 | 1/2 |
| 15 | S100-102-086-ZF1-15 | Drawer Support | 3 | 2/2 |
| 16 | S100-102-086-ZF1-16 | Drawer Base Large | 3 | 2/2 |
| 17 | S100-102-086-ZF1-17 | Drawer Base Small | 2 | 2/2 |
| 18 | S100-102-086-ZF1-18 | Back Panel | 2 | 1/2 |
| 19 | S100-102-086-ZF1-19 | Right Drawer Front Small | 1 | 2/2 |

HARDWARE LIST

| No. | Part Name | | Qty |
|-----|----------------------------|---|-----|
| A | Wooden Dowel (6x25mm) |  | x36 |
| B | 65mm Screw (4x65mm) |  | x12 |
| C | 14mm Screw (3.5x14mm) |  | x50 |
| D | 38mm Screw (4x38mm) |  | x23 |
| E | Cam Bolt (8032T) |  | x21 |
| F | Cam Nut (1512) |  | x21 |
| G | 10" Handle (192mm) |  | x5 |
| H | 20mm Handle Screw |  | x10 |
| I | 14" Drawer Slide |  | x5 |
| J | PVC L - Bracket |  | x2 |
| K | Plastic Foot |  | x6 |
| L | 6/8" Nail |  | x45 |
| M | Wall Fixation (4x20mm=1pc) |  | x1 |
| N | Screw Cover (Sticker 12mm) |  | x12 |




TIPS FOR FITTINGS CAM-LOCKS



CAMBOLT

Tighten until shoulder in flush with panel. Do not overtighten or undertighten (see example below)

Cam bolt head needs to be in centre




STEP 1


PARTS REQUIRED

1 - LEFT SIDE PANEL x1

2 - RIGHT SIDE PANEL x1






HARDWARE REQUIRED

C  3.5x14mm 16

I  04

K  04

TOOLS REQUIRED




STEP 2

PARTS REQUIRED


3 - CENTRE PANEL x1

HARDWARE REQUIRED






C  3.5x14mm 04

E  02

F  02

I  01

TOOLS REQUIRED






STEP 3



PARTS REQUIRED

| | |
|--------------------|----|
| 9 - CROSSBAR | x2 |
| 10- CENTRE SUPPORT | x2 |
| 11- SUPPORT TOP | x2 |
| 12- SUPPORT PANEL | x2 |

HARDWARE REQUIRED

| | | |
|---|---|----|
| A |  | 16 |
| F |  | 02 |
| K |  | 02 |

TOOLS REQUIRED






STEP 4

PARTS REQUIRED

| | |
|------------------|----|
| 3 - CENTRE PANEL | x1 |
| 11- SUPPORT TOP | x2 |

HARDWARE REQUIRED


TOOLS REQUIRED




STEP 5

PARTS REQUIRED




- 2 - RIGHT SIDE PANEL x1
- 9 - CROSSBAR x2
- 10 - CENTRE SUPPORT x2
- 12 - SUPPORT PANEL x1



HARDWARE REQUIRED

- B  06
4x65mm


TOOLS REQUIRED




STEP 6

PARTS REQUIRED




- 1 - LEFT SIDE PANEL x1
- 12 - SUPPORT PANEL x1



HARDWARE REQUIRED


- B  06
4x65mm

TOOLS REQUIRED




STEP 7


PARTS REQUIRED



HARDWARE REQUIRED



TOOLS REQUIRED






STEP 8



PARTS REQUIRED



HARDWARE REQUIRED




TOOLS REQUIRED




STEP 9

PARTS REQUIRED


8 - TOP PANEL x1







HARDWARE REQUIRED

C  04
3.5x14mm

TOOLS REQUIRED




When Fitting Cams
Ensure the starting position is correct before you insert the connecting bolt, turn clockwise until secure.




STEP 10


PARTS REQUIRED

18 - BACK PANEL x2








HARDWARE REQUIRED

C  02
3.5x14mm

L  45

TOOLS REQUIRED



STEP 11


PARTS REQUIRED

6 - LEFT DRAWER SIDE x5

7 - RIGHT DRAWER SIDE x5



15- DRAWER SUPPORT x3

HARDWARE REQUIRED

A  20

F  13

TOOLS REQUIRED



STEP 12


PARTS REQUIRED

4- DRAWER FRONT LARGE x3



5- LEFT DRAWER FRONT SMALL x1

19-RIGHT DRAWER FRONT SMALL x1

HARDWARE REQUIRED

E  13

TOOLS REQUIRED



STEP 13

PARTS REQUIRED


6 - LEFT DRAWER SIDE x5

7 - RIGHT DRAWER SIDE x5




13- DRAWER BACK LARGE x3

15- DRAWER SUPPORT x3

HARDWARE REQUIRED

D  15


TOOLS REQUIRED



STEP 14


PARTS REQUIRED

16 - DRAWER BASE LARGE x3



HARDWARE REQUIRED


TOOLS REQUIRED



STEP 15




PARTS REQUIRED

4 - DRAWER FRONT LARGE x3




HARDWARE REQUIRED

TOOLS REQUIRED





STEP 16

PARTS REQUIRED





HARDWARE REQUIRED

G  03


H  06

TOOLS REQUIRED





STEP 17



PARTS REQUIRED



HARDWARE REQUIRED



TOOLS REQUIRED




STEP 18




PARTS REQUIRED



HARDWARE REQUIRED




TOOLS REQUIRED



STEP 19


PARTS REQUIRED

17- DRAWER BASE SMALL x2



HARDWARE REQUIRED

TOOLS REQUIRED




STEP 20

PARTS REQUIRED


5- LEFT DRAWER FRONT SMALL x1

19-RIGHT DRAWER FRONT SMALL x1





HARDWARE REQUIRED

TOOLS REQUIRED




When Fitting Cams
 Ensure the starting position is correct before you insert the connecting bolt, turn clockwise until secure.




STEP 21



PARTS REQUIRED



HARDWARE REQUIRED




TOOLS REQUIRED





STEP 22





PARTS REQUIRED



HARDWARE REQUIRED






TOOLS REQUIRED




STEP 23

PARTS REQUIRED



HARDWARE REQUIRED

TOOLS REQUIRED




!
PLEASE NOTE THE CLEAR PROTECTIVE FILM WHICH NEEDS REMOVING FROM THE GLOSS FINISH.

STEP 24

WARNING

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices. Please make sure you use fixings suitable for the walls in your home.



HARDWARE REQUIRED



TOOLS REQUIRED

