


NEVADA DRESSING TABLE SET ASSEMBLY INSTRUCTIONS





IMPORTANT FOR DOMESTIC USE ONLY

PLEASE READ BEFORE YOU CONTINUE FURTHER

CARE AND MAINTENANCE

- After unpacking this product please keep the original packaging in case it needs to be returned for any reason.
- Please ensure all fittings and parts are present before commencing with assembly.
 - Never drag or push products as this could cause damage to the joints making it inferior.
 - We strongly recommend that you keep children away from your work area.
 - We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.
 - Assemble this product as close to its final position as possible.
 - Do not place this product next to a radiator or in direct sunlight.
 - Do not drag or push items across your high gloss furniture as this may cause the surface to scratch
 - Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.
 - Make sure any spillage is wiped off immediately.
 - Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.
 - For general cleaning use a soft cotton or micro fibre cloth, and do not use detergents of any kind.
 - From time to time it may be necessary to tighten fittings, regular inspections should be carried out.
 - Do not place on a wet or damp floor as staining may occur to your floor.























TOOLS REQUIRED

***Please Note:***

The below parts have all been stamped with the part number to help identify them during assembly.


Part Number	Part Description	Quantity	Carton
1	Left Chest Side Panel	1	1/2
2	Front Baseboard	1	1/2
3	Back Baseboard	1	1/2
4	Right Chest Side Panel	1	1/2
5	Back Crossbar	1	1/2
6	Upper Crossbar	2	1/2
7	Right Table Side Panel	1	1/2
8	Top Panel	1	2/2
9	Back Panel	2	1/2
10	Stool Side Panel	2	2/2
11	Stool Crosspiece	2	2/2
12	Stool Seat	1	2/2
13	Mirror Base Panel	1	1/2
14	Mirror Side Panel	2	2/2
15	Mirror Panel	1	2/2
16	Drawer Side	8	2/2
17	Drawer Back	4	2/2
18	Drawer Front	4	1/2
19	Drawer Bottom	4	2/2

FITTINGS LIST


<p>A</p>  <p>Flat Head Screw Ø4,0 x 14mm (24x)</p> <p>+/2</p>	<p>B</p>  <p>Flat Head Screw Ø6,0 x 8mm (16x)</p> <p>+/2</p>	<p>C</p>  <p>Flan Head Screw Ø4,0 x 20mm (8x)</p> <p>+/1</p>	<p>D</p>  <p>Flan Head Screw Ø3,5 x 30mm (2x)</p> <p>+/1</p>
<p>E</p>  <p>Flat Head Screw Ø4,0 x 50mm (4x)</p> <p>+/1</p>	<p>F</p>  <p>Flat Head Screw Ø 4,0 x 60mm (4x)</p> <p>+/1</p>	<p>G</p>  <p>+/2 Dowel Ø6,0 x 30mm (62x)</p>	
<p>H</p>  <p>Nail 10 x 10 (66x)</p> <p>+/4</p>	<p>I</p>  <p>Flat Head Screw Ø 4,0 x 45mm (18x)</p> <p>+/2</p>	<p>J</p>  <p>Cam Bolt (18x)</p> <p>+/2</p>	<p>K</p>  <p>Mirror Support (2x)</p>
<p>L</p>  <p>Flan Head Screw Ø3,5 x 12mm (4x)</p> <p>+/1</p>	<p>M</p>  <p>Cam Nut Ø12mm (18x)</p> <p>+/2</p>	<p>N</p>  <p>Plastic Foot (10x)</p> <p>+/2</p>	<p>O</p>  <p>Hole Plugs (28x)</p> <p>+/2</p>
<p>P</p>  <p>Glue (3x)</p>	<p>Q</p>  <p>Strap (2x)</p>	<p>R</p>  <p>Washer (4x)</p> <p>+/1</p>	<p>S</p>  <p>Handle (4x)</p>
<p>T</p>  <p>Drawer Runners (4x)</p>		<p>U</p>  <p>Back Panel Strip (1x)</p>	
<p>V</p>  <p>Black Flat Head Screw Ø 3,0 x 16mm (8x)</p> <p>+/2</p>			

TIPS FOR FITTINGS CAM-LOCKS

WHEN FITTING CAM NUT, ENSURE STARTING POSITION IS CORRECT BEFORE YOU INSERT CONNECTING CAM BOLT TURN CLOCKWISE UNTIL SECURE




CORRECT **WRONG**



Cam bolt head needs to be in centre

CAMBOLT

Tighten until shoulder in flush with panel. Do not overtighten or undertighten (see example beside)



STEP 1

PARTS REQUIRED

2 - FRONT BASEBOARD x1


3 - BACK BASEBOARD x1

5 - BACK CROSSBAR x1

6 - UPPER CROSSBAR x2



11 - STOOL CROSSPIECE x2

HARDWARE REQUIRED

G  20
Ø6,0 x 30mm

P  01
Glue

TOOLS REQUIRED




STEP 2

PARTS REQUIRED



8 - TOP PANEL x1

12 - STOOL SEAT x1

HARDWARE REQUIRED

J  10
Cam Bolt

TOOLS REQUIRED





STEP 3


PARTS REQUIRED

4 - RIGHT CHEST SIDE PANEL x1

HARDWARE REQUIRED


B  08
Ø6,0 x 8mm

G  02
Ø6,0 x 30mm


H  02
10 x 10

N  02



P  01

T  04
Right


TOOLS REQUIRED




To Assemble the Drawer Slide, Please Follow Step as Below



Detail 1



Detail 3



Detail 4


STEP 4


PARTS REQUIRED

1 - LEFT CHEST SIDE PANEL x1

HARDWARE REQUIRED


B  08
Ø6,0 x 8mm

G  02
Ø6,0 x 30mm


H  02
10 x 10

N  02



P  01

T  04
Left


TOOLS REQUIRED




To Assemble the Drawer Slide, Please Follow Step as Below



Detail 1



Detail 4



Detail 5


STEP 5


PARTS REQUIRED

7 - RIGHT TABLE SIDE PANEL x1


10 - STOOL SIDE PANEL x2

HARDWARE REQUIRED



G  06
Ø6,0 x 30mm

H  06
10 x 10


N  06

P  01
Glue

TOOLS REQUIRED



Detail 1



Detail 4

STEP 6

PARTS REQUIRED


1 - LEFT CHEST SIDE PANEL x1

2 - FRONT BASEBOARD x1

3 - BACK BASEBOARD x1




4 - RIGHT CHEST SIDE PANEL x1

HARDWARE REQUIRED


I  04
Ø4,0x45mm

P  01
Glue

TOOLS REQUIRED




Detail 1



Detail 6



STEP 7

PARTS REQUIRED






- 5 - BACK CROSSBAR x1
- 6 - UPPER CROSSBAR x2
- 7 - RIGHT TABLE SIDE PANEL x1


HARDWARE REQUIRED

- I  06
Ø 4,0x45mm
- P  01


TOOLS REQUIRED



Detail 1




Detail 6



Detail 6



STEP 8

PARTS REQUIRED






- 8 - TOP PANEL x1


HARDWARE REQUIRED

- M  06
- P  01


TOOLS REQUIRED



Detail 1




Detail 7




STEP 9


PARTS REQUIRED

9 - BACK PANEL x2




HARDWARE REQUIRED

H  10 x 10 24



U  01

L  Ø3,5 x 12mm 04


TOOLS REQUIRED



* For your future reference
Order Number should be here



Detail 8



Detail 16

STEP 10


PARTS REQUIRED

16 - DRAWER SIDE x8

17 - DRAWER BACK x4

18 - DRAWER FRONT x4




HARDWARE REQUIRED

J  08

G  32
Ø6,0 x 30mm

P  01

TOOLS REQUIRED




STEP 11

PARTS REQUIRED

16 - DRAWER SIDE x8




17 - DRAWER BACK x4

HARDWARE REQUIRED

I  08
Ø 4,0x45mm


P  01

TOOLS REQUIRED



STEP 12

PARTS REQUIRED





18 - DRAWER FRONT x4

HARDWARE REQUIRED



TOOLS REQUIRED


X4



Detail 1

STEP 13


PARTS REQUIRED





HARDWARE REQUIRED




TOOLS REQUIRED



X4




Detail 10




STEP 14

PARTS REQUIRED




19 - DRAWER BOTTOM x4




HARDWARE REQUIRED



TOOLS REQUIRED




X4




STEP 15


PARTS REQUIRED






HARDWARE REQUIRED



TOOLS REQUIRED




X4



STEP 16




PARTS REQUIRED



HARDWARE REQUIRED



TOOLS REQUIRED





Detail 12

STEP 17




PARTS REQUIRED




HARDWARE REQUIRED




TOOLS REQUIRED



Detail 1




Detail 6




STEP 18


PARTS REQUIRED





12 - STOOL SEAT x1

HARDWARE REQUIRED


M  04

P  01


TOOLS REQUIRED



Detail 1



Detail 7




STEP 19


PARTS REQUIRED


13 - MIRROR BASE PANEL x1

14 - MIRROR SIDE PANEL x2




HARDWARE REQUIRED

F  04
Ø 4,0 x 60mm


V  04
Ø 3,0 x 16mm

K  02


TOOLS REQUIRED




Detail 13



Detail 14



Detail 14.1




Detail 14.2


STEP 20

PARTS REQUIRED





15 - MIRROR PANEL x1

HARDWARE REQUIRED

V  04
Ø 3,0 x 16mm

K  02

TOOLS REQUIRED





Detail 15

Detail 15.1


STEP 21

PARTS REQUIRED





STEP 22



PARTS REQUIRED



HARDWARE REQUIRED





See the last page





Detail 16


STEP 23



TOOLS REQUIRED



Drawer Adjustment Drawer Lock



Detail 23

WARNING

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices.

Please make sure you use fixings suitable for the walls in your home.

