


BROOKLYN 3 DRAWER BEDSIDE ASSEMBLY INSTRUCTIONS



IMPORTANT FOR DOMESTIC USE ONLY PLEASE READ BEFORE YOU CONTINUE FURTHER

THE PRODUCT YOU HAVE PURCHASED WILL GIVE YOU MANY YEARS OF SERVICE IF YOU FOLLOW THE GUIDELINES FOR ITS SAFE ASSEMBLY AND PERIODIC MAINTENANCE AND CLEANING.

ASSEMBLE ON A SOFT CLEAN SURFACE.

DO NOT USE ANY TOOLS OTHER THAN THOSE SHOWN.


ANY SPANNERS OR ALLEN KEYS REQUIRED ARE INCLUDED WITH THE FITTINGS KIT.

DO NOT FOR ANY REASON USE A POWER TOOL TO ASSEMBLE THIS PRODUCT. ITS USE WILL INVALIDATE ANY CLAIM YOU MAY HAVE AND COULD MAKE THIS PRODUCT UNSAFE.

DEPENDING ON THE AMOUNT OF USE THIS PRODUCT RECEIVES IT MAY BE NECESSARY TO TIGHTEN UP THE FIXINGS FROM TIME TO TIME. THIS IS COMPLETELY NORMAL FOR ANY FLAT PACK FURNITURE. DO NOT OVERTIGHTEN FIXING.

FOR CLEANING, YOU MAY USE A DAMP CLOTH (NOT WET) DO NOT USE POLISH, DETERGENT OR CHEMICAL CLEANERS.





THE SURFACE OF THIS ITEM IS NOT HEAT RESISTANT. ALWAYS USE A PLACE MAT UNDER HOT OR COLD ITEMS TO PREVENT MARKING.




PART LIST

<u>Part Number</u>	<u>Part Code</u>	<u>Part Description</u>	<u>Quantity</u>	<u>Carton</u>
1	S100-103-092-EU1-01	Side Panel - Left	1	1/1
2	S100-103-092-EU1-02	Crossbar	2	1/1
3	S100-103-092-EU1-03	Side Panel - Right	1	1/1
4	S100-103-092-EU1-04	Top Panel	1	1/1
5	S100-103-092-EU1-05	Bottom Panel	1	1/1
6	S100-103-092-EU1-06	Back Panel	1	1/1
7	S100-103-092-EU1-07	Drawer Back	3	1/1
8	S100-103-092-EU1-08	Drawer Side - Left	3	1/1
9	S100-103-092-EU1-09	Drawer Side - Right	3	1/1
10	S100-103-092-EU1-10	Drawer Front	3	1/1
11	S100-103-092-EU1-11	Drawer Base	3	1/1


HARDWARE LIST

A		DOWEL 6 X 30MM	36 PCS
B		ALLEN KEY	1 PC
C		SCREW M6 X 50MM	4 PCS
D		SCREW M3.5 X 16MM	18 PCS
E		TACK	18 PCS
F		SCREW M4 X 50MM	16 PCS
G		HANDLE	3 PCS
H		WOOD FOOT	4 PCS
I		CAM BOLT + CAM NUT	14 SET
J		HANDLE SCREW 19MM	3 PCS
K		SCREW M3.5 X 12MM	36 PCS
L		DRAWER RUNNER A - L/R	6 PCS
M		DRAWER RUNNER B - L/R	6 PCS
N		SCREW M4 X 38MM	6 PCS



(SCREWDRIVER NOT PROVIDED)

USE A FLAT HEAD SCREWDRIVER TO TIGHTEN THE CAM NUTS. A QUARTER TURN CLOCKWISE IS ALL THAT IS NEEDED.



STEP 1 - PUSH CAM BOLT INTO INSERT.

STEP 2 - ALIGN THE CAM BOLT WITH THE HOLE AND PUSH TOGETHER UNTIL FLUSH. (MAKE SURE THE ARROW OF THE CAM LOCK IS POINTING TOWARD THE EDGE OF THE PANEL.)


STEP 3 - THE HEAD OF THE BOLT GOES INTO THE WIDE MOUTH OF THE CAM LOCK. YOU THEN TURN THE LOCK SO THE NARROW PART CLOSSES OVER THE BOLT.

STEP 1



PARTS REQUIRED

1 - SIDE PANEL - LEFT x1

HARDWARE REQUIRED

- A  04
- I  02
- K  12
- L  03

TOOLS REQUIRED




STEP 2



PARTS REQUIRED

3 - SIDE PANEL - RIGHT x1

HARDWARE REQUIRED

- A  04
- I  02
- K  12
- L  03

TOOLS REQUIRED



STEP 3

PARTS REQUIRED

2 - CROSSBAR x2



4 - TOP PANEL x1

HARDWARE REQUIRED

A  04

I  04

TOOLS REQUIRED



STEP 4


PARTS REQUIRED

1 - SIDE PANEL -LEFT x1

2 - CROSSBAR x2

HARDWARE REQUIRED


TOOLS REQUIRED



STEP 5


PARTS REQUIRED

3 - SIDE PANEL - RIGHT x1



HARDWARE REQUIRED


TOOLS REQUIRED



STEP 6


PARTS REQUIRED

4 - TOP PANEL x1



HARDWARE REQUIRED


TOOLS REQUIRED



STEP 7

PARTS REQUIRED


5 - BOTTOM PANEL x1



HARDWARE REQUIRED


C  04

TOOLS REQUIRED




STEP 8

PARTS REQUIRED





HARDWARE REQUIRED

F  16

H  04


TOOLS REQUIRED



STEP 9

PARTS REQUIRED



6 - BACK PANEL x1



HARDWARE REQUIRED

E  18

TOOLS REQUIRED



STEP 10

PARTS REQUIRED

7 - DRAWER BACK x3

8 - DRAWER SIDE-LEFT x3

9 - DRAWER SIDE-RIGHT x3

10 - DRAWER FRONT x3



HARDWARE REQUIRED

A  24

I  06

N  06


TOOLS REQUIRED



STEP 11

PARTS REQUIRED

11 - DRAWER BASE x3





HARDWARE REQUIRED

G  03


J  03

K  12

TOOLS REQUIRED




X3



STEP 12

PARTS REQUIRED





HARDWARE REQUIRED

D  18

M  06


TOOLS REQUIRED



X3

STEP 13


PARTS REQUIRED



X3


HARDWARE REQUIRED

TOOLS REQUIRED



STEP 14

PARTS REQUIRED



HARDWARE REQUIRED

TOOLS REQUIRED

