


# BLACK WOOD GRAIN LISBON 4 DOOR 2 DRAWER WARDROBE ASSEMBLY INSTRUCTIONS



## IMPORTANT

### PLEASE READ BEFORE YOU CONTINUE FURTHER FOR DOMESTIC USE ONLY

THE PRODUCT YOU HAVE PURCHASED WILL GIVE YOU MANY YEARS OF SERVICE IF YOU FOLLOW THE GUIDELINES FOR ITS SAFE ASSEMBLY AND PERIODIC MAINTENANCE AND CLEANING.

ASSEMBLE ON A SOFT CLEAN SURFACE.

DO NOT USE ANY TOOLS OTHER THAN THOSE SHOWN.


ANY SPANNERS OR ALLEN KEYS REQUIRED ARE INCLUDED WITH THE FITTINGS KIT.

DO NOT FOR ANY REASON USE A POWER TOOL TO ASSEMBLE THIS PRODUCT. ITS USE WILL INVALIDATE ANY CLAIM YOU MAY HAVE AND COULD MAKE THIS PRODUCT UNSAFE.

DEPENDING ON THE AMOUNT OF USE THIS PRODUCT RECEIVES IT MAY BE NECESSARY TO TIGHTEN UP THE FIXINGS FROM TIME TO TIME. THIS IS COMPLETELY NORMAL FOR ANY FLAT PACK FURNITURE. DO NOT OVERTIGHTEN FIXING.

FOR CLEANING, YOU MAY USE A DAMP CLOTH (NOT WET) DO NOT USE POLISH, DETERGENT OR CHEMICAL CLEANERS.



THE SURFACE OF THIS ITEM IS NOT HEAT RESISTANT. ALWAYS USE A PLACE MAT UNDER HOT OR COLD ITEMS TO PREVENT MARKING.





## PART LIST

Part Number	Part Code	Part Description	Quantity	Carton
1	S100-101-123-101-EU1-01	Centre Panel	1	2/4
2	S100-101-123-101-EU1-02	Shelf Panel- Right	1	3/4
3	S100-101-123-101-EU1-03	Top Panel	1	3/4
4	S100-101-123-101-EU1-04	Base Panel	1	3/4
5	S100-101-123-101-EU1-05	Base Front Apron	1	2/4
6	S100-101-123-101-EU1-06	Base Back Apron	1	2/4
7	S100-101-123-101-EU1-07	Right Side Panel	1	1/4
8	S100-101-123-101-EU1-08	Back Crossbars	2	3/4
9	S100-101-123-101-EU1-09	Left Side Panel	1	1/4
10	S100-101-123-101-EU1-10	Back Panel	4	1/4 & 4/4
11	S100-101-123-101-EU1-11	Drawer Back	2	2/4
12	S100-101-123-101-EU1-12	Drawer Side - Left	2	3/4
13	S100-101-123-101-EU1-13	Drawer Side - Right	2	3/4
14	S100-101-123-101-EU1-14	Drawer Front	2	2/4
15	S100-101-123-101-EU1-15	Drawer Base	2	2/4
16	S100-101-123-101-EU1-16	Drawer Bottom Support Rail	2	3/4
17	S100-101-123-101-EU1-17	Mirror Door Panel - Left	1	4/4
18	S100-101-123-101-EU1-18	Mirror Door Panel - Right	1	4/4
19	S100-101-123-101-EU1-19	Small Door Panel - Left	1	4/4
20	S100-101-123-101-EU1-20	Small Door Panel - Right	1	4/4
21	S100-101-123-101-EU1-21	Shelf Panel- Left	1	2/4

## HARDWARE LIST






A		DOWEL 6x30MM	50 PCS
B		BOLT M6x50MM	18 PCS
C		BOLT M7x60MM	2 PCS
D		SCREW M3.5x16MM	44 PCS
E		TACK	48 PCS
F		SCREW M4 X 38MM	8 PCS
G		HANDLE	6 PCS
H		TAPPING SCREW M8 X 12MM	24 PCS
I		HANGING RAIL SUPPORT	4 PCS
J		HANGING RAIL (A&B)	2 PCS
K		PLASTIC H STRIP	3 PCS
L		SHELF SUPPORT	4 PCS
M		PVC STOPPER	2 PCS
N		HINGES 7/8	6 PCS

O		HINGES 5/8	6 PCS
P		DRAWER RUNNER A (L&R)	4 PCS
Q		DRAWER RUNNER B (L&R)	4 PCS
R		SCREW M4 X 30MM	4 PCS
S		HANDLE SCREW 19MM	12 PCS
T		ALLEN KEY	1 PC
U		SCREW M3.5x12MM	24 PCS
V		CAM BOLT+CAM NUT	4 SETS
W		PLASTIC FOOT	5 PCS
X		PLASTIC FOOT	1 PC
Y		SCREW M4 X 50MM	4 PCS
Z		ANTI - TIP STRAP	2 PCS
Z1		SCREW M4 X 16MM	2 PCS



(SCREWDRIVER NOT PROVIDED)

USE A FLAT HEAD SCREWDRIVER TO TIGHTEN THE CAM NUTS. A QUARTER TURN CLOCKWISE IS ALL THAT IS NEEDED.



STEP 1 - PUSH CAM BOLT INTO INSERT

STEP 2 - ALIGN THE CAM BOLT WITH THE HOLE AND PUSH TOGETHER UNTIL FLUSH. ( MAKE SURE THE ARROW OF THE CAM LOCK IS POINTING TOWARD ON THE EDGE OF THE PANEL.)

STEP 3 - THE HEAD OF THE BOLT GOES INTO THE WIDE MOUTH OF THE CAM LOCK. YOU THEN TURN THE LOCK SO THE NARROW PART CLOSES OVER THE BOLT.

# STEP 1

**PARTS REQUIRED**

1 - CENTRE PANEL x1

**HARDWARE REQUIRED**

A  04



I  02

L  02

U  12

P  02

**TOOLS REQUIRED**



# STEP 2

**PARTS REQUIRED**

2 - SHELF PANEL - RIGHT x1

3 - TOP PANEL x1



**HARDWARE REQUIRED**

A  08

D  02

M  02

**TOOLS REQUIRED**



# STEP 3


**PARTS REQUIRED**

4 - BASE PANEL	x1
5 - BASE FRONT APRON	x1
6 - BASE BACK APRON	x1
8 - BACK CROSSBARS	x2

**HARDWARE REQUIRED**

A		26
---	---	----

**TOOLS REQUIRED**



# STEP 4



**PARTS REQUIRED**

7 - RIGHT SIDE PANEL	x1
9 - LEFT SIDE PANEL	x1

**HARDWARE REQUIRED**

I		02
L		02
U		12
P		02

**TOOLS REQUIRED**



# STEP 5

**PARTS REQUIRED**


1 - CENTRE PANEL x1

2 - SHELF PANEL - RIGHT x1

**HARDWARE REQUIRED**

B  02

**TOOLS REQUIRED**




# STEP 6


**PARTS REQUIRED**

3 - TOP PANEL x1



4 - BASE PANEL x1



**HARDWARE REQUIRED**

Y  04

**TOOLS REQUIRED**




## STEP 7

**PARTS REQUIRED**

5 - BASE FRONT APRON x1


6 - BASE BACK APRON x1

7 - RIGHT SIDE PANEL x1




**HARDWARE REQUIRED**

B  07

C  01

**TOOLS REQUIRED**




## STEP 8


**PARTS REQUIRED**

8 - BACK CROSSBARS x2

9 - LEFT SIDE PANEL x1




**HARDWARE REQUIRED**

B  09

C  01


**TOOLS REQUIRED**



# STEP 9

**PARTS REQUIRED**

10 - BACK PANEL x4



**HARDWARE REQUIRED**

D  06



E  32

K  03


W  05

X  01

**TOOLS REQUIRED**



PLEASE INSERT THE BACK PANEL INTO THE UNIT



# STEP 10

**PARTS REQUIRED**

11 - DRAWER BACK x2

12 - DRAWER SIDE - LEFT x2



13 - DRAWER SIDE - RIGHT x2

**HARDWARE REQUIRED**

A  08

F  08


**TOOLS REQUIRED**



# STEP 11

**PARTS REQUIRED**

14 - DRAWER FRONT x2




**HARDWARE REQUIRED**

G  02

S  04

V  04

**TOOLS REQUIRED**




# STEP 12

**PARTS REQUIRED**

15 - DRAWER BASE x2

16 - DRAWER BOTTOM SUPPORT RAIL x2



**HARDWARE REQUIRED**

A  04




D  12

E  16

Q  04



R  04

**TOOLS REQUIRED**




# STEP 13

PARTS REQUIRED



HARDWARE REQUIRED

TOOLS REQUIRED



# STEP 14

PARTS REQUIRED

17 - MIRROR DOOR PANEL - LEFT x1

20 - SMALL DOOR PANEL - RIGHT x1

HARDWARE REQUIRED


D  12

G  02

N  06

S  04

TOOLS REQUIRED



# STEP 15

## PARTS REQUIRED

18 - MIRROR DOOR PANEL - RIGHT x1

19 - SMALL DOOR PANEL - LEFT x1

## HARDWARE REQUIRED



D  12

G  02

O  06

S  04

## TOOLS REQUIRED




# STEP 16

## PARTS REQUIRED

18 - MIRROR DOOR PANEL - RIGHT x1

20 - SMALL DOOR PANEL - RIGHT x1





## HARDWARE REQUIRED

H  12

J  02

## TOOLS REQUIRED




# STEP 17

**PARTS REQUIRED**

17 - MIRROR DOOR PANEL - LEFT x1

19 - SMALL DOOR PANEL - LEFT x1



21 - SHELF PANEL - LEFT x1




**HARDWARE REQUIRED**

H  12


**TOOLS REQUIRED**




1. VERTICAL ADJUSTMENT VIA SLOT IN THE MOUNTING PLATE



2. LATERAL ADJUSTMENT BY SCREW ADJUSTING




3. FRONT-TO-BACK BY THE SLACKING THE HINGE ARM MOUNTING SCREW



# STEP 18

**PART REQUIRED**




**HARDWARE REQUIRED**

Z  02

Z1  02

**TOOLS REQUIRED**



# WARNING

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices. Please make sure you use fixings suitable for the walls in your home.

